

EMFS

IP30



Enclosure  
Rozvodnice  
Rozvodnica  
Obudowa  
Carcasă  
Verteilerschrank  
Armoires électriques  
Шкаф  
Кутія  
Kućište  
Elosztó  
Spinta  
Sadalne  
Quadri  
Envolvente  
Bijlage

Mounting instruction  
Montážní návod  
Montážny návod  
Instrukcja montażu  
Instruțiuni de asamblare  
Montageanweisung  
Instructions de montage  
Инструкция по монтажу  
Monteringsanvisning  
Istruzioni di montaggio  
Instrucciones de montaje  
Összeszerelési útmutató  
Asennusohjeita

Montage-instructies  
Instruções de montagem  
Navodila za montažo  
Οδηγίες Εγκατάστασης  
Инструкции за инсталиране  
Monteringsvejledning  
Montažu upute  
Montavimo instrukcijos  
Instalēšanas instrukcijas  
Uputstvo za montažu  
Paigaldusjuhendid  
Інструкція з монтажу

Caution: Installation by electricians only

Varování: Montáž pouze osobou s elektrotechnickou kvalifikací

Varovanie: Montáž smie vykonávať iba osoba s elektrotechnickou kvalifikáciou

Uwaga: Montaż tylko przez uprawnionych instalatorów

Atentie: Instalare numai de catre electricieni

Vorsicht: Montage nur durch Eletrofachkräfte

Attention: Montage uniquement par un électricien

Осторожно: Установка данного оборудования производится только специалистом – электриком

Attenzione: L'installazione deve essere eseguita solamente da personale qualificato

Atención: Este dispositivo debe ser manipulado únicamente por personal cualificado

Figyelem: Szerelést kizárólag szakember végezheti

Внимание; Монтаж само от ел.специалисти


Démesio: montavimo darbus gali atlikti tik kvalifikuotas specialistas-elektrikas

Upozorenje: Montažu izvodi samo stručno lice


Обережно: монтаж виконує виключно електрик

**NOARK**

A




B



C




D



E a





E b




F




G




**EMFS2**




**EMFS3**




**EMFS4**



**EMFS5**



**EMFS6**




H



I



J



	(X)	(Y)	(Z)	(A)	(B)
<b>EMFS2 48</b>	566	489	137	566	440
<b>EMFS3 72</b>	566	630	137	566	581
<b>EMFS4 96</b>	566	771	137	566	722
<b>EMFS5 120</b>	566	912	137	566	863
<b>EMFS6 144</b>	566	1053	137	566	1004
<b>EMFS2 66</b>	730	489	137	730	440
<b>EMFS3 99</b>	730	630	137	730	581
<b>EMFS4 132</b>	730	771	137	730	722
<b>EMFS5 165</b>	730	912	137	730	863
<b>EMFS6 198</b>	730	1053	137	730	1004