

Isolator  
Hlavní vypínač  
Vypínač  
Rozłącznik izolacyjny  
Intreruptor  
Hauptlastschalter  
Interrupteur  
Выключатель нагрузки  
Заключваем в позицич OFF  
Шалтер(товаров прекьсвач)  
Rastavljač

NOARK

Mounting instructions

Montážní návod

Montážne inštrukcie

Instrukcja montazu

Instruçiuni de asamblare

Montageanweisung

Instructions de montage

Инструкция по монтажу

Monteringsanvisning

Istruzioni di montaggio

Instrucciones de montaje

Összeszerelési útmutató

Asennusohjeita

Montage-instructies

Instruções de montagem

Navodila za montažo

Οδηγίες Εγκατάστασης

Инструкции за инсталиране

Monteringsvejledningen

Montažu upute

Surinkimo instrukcijos

Instalēšanas instrukcijas

Скупштина упутство

Paigaldusjuhendid

Caution: Installation by electricians only

Varování: Montáž pouze osobou s elektrotech. kvalifikací

Varovanie: Montáž iba osobou s elektrotech. kvalifikáciou

Uwaga: Montaż tylko przez uprawnionych instalatorów



Atenție: Instalare numai de catre electricieni

Vorsicht: Montagenur durch Elektrofachkräfte

Attention: Montage uniquement par un électricien


Осторожно: Монтаж только электрика


1P/2P/3P/4P










2

CLICK!





	 Z1
 (mm <sup>2</sup> )	1-10mm <sup>2</sup>
 (Nm)	1-1.5Nm



# NOARK



Printed with environment-friendly paper

Copyright Noark. All Rights Reserved

[www.noark-electric.eu](http://www.noark-electric.eu)